



Admiral

by designer Troels Bøgely

Model: GV-10
Material: glass fibre reinforced plastic (GFP)
Installation: vertical

Installation of the uridan water free urinals is very simple.

If you retrofitting existing flushing urinals with uridan waterless urinals, please ensure that the sewer line is jetted and clean of uric scale before installation.

The uridan urinals work without water, and therefore should only be connected with \varnothing 50 mm drainpipes. Installation should be carried out by authorized plumbers.

1. Mark holes for fitting No. (1) and install it.
2. Mount the wastewater pipes using the sketch. Hold the urinal against the wall and push firmly onto the fitting No. (1).
3. Fill the waste trap Pos. (B) full with water.
4. Insert the stainless steel cover Pos. (A).
5. Pour 1 bottle uriLOCK (0,3 liter) over the cover.
6. Seal the gap between the wall and the urinal with silicone. **Please note:** Do not put any silicone on the lower tip of the urinal!
7. The uridan urinal is now ready for use!

Please leave customer care booklet, cleaning and maintenance instructions and suction device with customer.

