



Type Compass

by designer uridan a/s

Model: GY-6

Material: glass fibre reinforced plastic (GFP)

Installation: vertical

Installation of the uridan® water free urinals is very simple.

If you have earlier had water flush urinals, the drainpipe should be cleaned before installation of uridan® urinals. Ensure that existing sewer pipes are well cleaned and don't have pre-existing blockages.

uridan® urinals work without water, and therefore should only be connected with \varnothing 50 mm drainpipe. Installation should be carried out by authorized plumbers.

1. Install bracket no. (20). The urinal hangs on this bracket.
2. uridan® urinal should be held against the wall and slide the urinal down to the waste outlet \varnothing 50mm.
3. Insert the small PVC pipe (B) in the water lock and afterwards fill the water lock with water.
4. Insert the stainless steel cover (A).
5. Then pour 1 bottle of 0,3 liter urilock® over the cover. **Important!** Never pour urilock® fluid before the stainless steel cover is insert.
6. Apply silicon sealant around the edge of the urinal - between the urinal and the wall & floor.
7. The uridan® urinal is now ready for use!

Please leave customer care booklet, uriclean® cleaning detergent and hook with customer.

